

# 1.0 Hardware installation

Figure 1.1 board layout





Figure 1.2 External cable connector



## 2.0 External Cable Connection

### 2.1 MC68HC11 packages

DEVICE	ROM	RAM	EEPROM	B2	B3	B4	B5	GND	XTAL		PACKAGE
				TxD	RxD	MB	RES				
HC11A8	E000H- FFFFH	0000H- 00FFH	B600H- B7FFH	21	20	2	17	1	7	8	PLCC52 DIP48 QFP64
				43	42	24	39	23	29	30	
				50	47	25	43	24	31	33	
HC(7)11E9	D000H- FFFFH	0000H- 01FFH	B600H- B7FFH	21	20	2	17	1	7	8	PLCC52 DIP48 QFP64 QFP52 SDIP56
				43	42	24	39	23	29	30	
				50	47	25	43	24	31	33	
				40	39	21	36	20	26	27	
				22	20	2	17	1	7	8	
HC811E2	---	0000H- 00FFH	F800H- FFFFH	21	20	2	17	1	7	8	PLCC52 DIP48 QFP64 QFP52 SDIP56
				43	42	24	39	23	29	30	
				50	47	25	43	24	31	33	
				40	39	21	36	20	26	27	
				22	20	2	17	1	7	8	
HC11E20	9000H- AFFFH + D000H- FFFFH	0000H- 02FFH	B600H- B7FFH	21	20	2	17	1	7	8	PLCC52 DIP48 QFP64 QFP52 SDIP56
				43	42	24	39	23	29	30	
				50	47	25	43	24	31	33	
				40	39	21	36	20	26	27	
				22	20	2	17	1	7	8	
HC(7)11G5	C000H- FFFFH	0000H- 01FFH	---	80	79	42	68	46	44	45	PLCC84
HC11N4	A000H- FFFFH	0080H- 037FH	0D80H- 0FFFH	79	78	76	75	70	73	74	QFP80
HC11F1	---	0000H- 03FFH	FE00H- FFFFH	29	28	2	17	1	6	7	PLCC68 QFP80
				64	63	32	50	31	36	37	
HC(7)11PH8	4000H- FFFFH	0080H- 087FH	0D00H- 0FFFH	73	72	20	70	3	66	67	PLCC84 TQFP112
				82	81	12	79	102	72	73	
HC(7)11L6	C000H- FFFFH	0000H- 01FFH	B600H- B7FFH	28	26	2	23	1	7	8	PLCC68 QFP64
COLOR	----	----	----								

## 2.1 MC68HC11 packages (continue)

DEVICE	ROM	RAM	EEPROM	B2 TxD	B3 RxD	B4 MB	B5 RES	GND	XTAL		PACKAGE
HC11KA4	A000H- FFFFH	0080H- 02FFH	0D80H- 0FFFH	62 1	61 64	59 62	58 61	67 6	57 60	56 59	PLCC68 QFP64
COLOR	----	----	----								

## 2.2 MC68HC05B6/16/32 packages

RAM	EEPROM	B2 TDx	B3 RDx	B4 PD4	B5 RES	B6 PD3	B7 TCP	Rvpp IRQ	GND	BQ		PACKAGE	NOTE
0050H- 00FFH	0100H- 01FFH	52 10 55	50 8 53	9 19 10	18 30 19	11 21 12	22 34 23	19 31 20	41 58 43	16 28 17	17 29 18	PLCC52 QFP64 SDIP56	
COLOR	---												

## 2.3 MC68HC705B16/16N/32 packages

RAM	EEPROM	B2 TDx	B3 RDx	B4 PD4	B5 RES	B6 PD3	B7 TCP	Rvpp IRQ	GND	BQ		PACKAGE	NOTE
0050H- 00FFH	0100H- 01FFH	52 10 55	50 8 53	--- --- ---	18 30 19	11 21 12	22 34 23	19 31 20	41 58 43	16 28 17	17 29 18	PLCC52 QFP64 SDIP56	9= +5V 12=GND 19=+5V 22=GND 10 = +5V 13=GND
COLOR	---												

\*ROM: B6=(0020H-004FH)&(0800H-1EFFH); B16=(0020H-004F)&(0300H-3DFDH); B32=(0400H-7DFFH).